



 HS3PIR1X

Contents (US) Contenu (FR) Inhalt (DE) Inhoud (NL) Sisältö (FI) Inhoud (PT) Contenido (ES) Contenido (IT) Conteúdo (BR) Περιεχόμενα (GR) Innihöll (IS)



x1



x2




20mm

x2












x2



- Ⓒ Set up Ⓓ Einrichtung Ⓔ Configuration
- Ⓕ Inställingen Ⓖ Asetus Ⓗ Opsettning
- Ⓜ Configurazione Ⓝ Configuración Ⓡ Configuração
- Ⓣ Подборка Ⓢ Installasjon Ⓚ Installation


- Ⓒ Location planning Ⓓ Planung des Montageortes
- Ⓕ Identification du meilleur emplacement Ⓖ Localiteplanning
- Ⓜ Sijainnin suunnittelu Ⓡ Planlægning af placering
- Ⓣ Posizionamento Ⓢ Planificación de la ubicación
- Ⓚ Planeamento de localização Ⓗ Xuporatuña Ⓡ Placering




Ⓒ Put alarm into learn mode for linking. Refer to online manual. Ⓓ Zum Einlernen Alarmanlage in den Programmiermodus versetzen. Siehe Handbuch. Ⓕ Mettre l'alarme en mode apprentissage pour la liaison. Consulter le manuel en ligne. Ⓖ Alarm in leermodus voor koppelen zetten. Zie de online handleiding. Ⓡ Aseta hälytin oppimistilaan linkitystä varten. Katso käsikirja verkosta. Ⓢ Sæt alarmen i programmeringsfunktion med henblik på tilslutning. Se online vejledningen. Ⓣ Mettere l'alarme in modalità di apprendimento per effettuare il collegamento. Fare riferimento al manuale online. Ⓚ Coloque la alarma en el modo de aprendizaje para el enlace. Consulte el manual en línea. Ⓗ Coloque o alarme no modo de aprendizagem para efectuar a ligação. Consulte o manual online. Ⓖ Βάλτε το συναγερμό σε λειτουργία μάθησης για ζεύξη. Ανατρέξτε στο εγχειρίδιο στο διαδίκτυο. Ⓡ Sätta larret i inlärningsläget för länkning. Se onlinehandboken.










- GB Installation DE Installation GR Installation
- IL Instalatie FR Asemnul OK Instalation
- IT Installazione ES Instalación PT Instalação
- GR Εγκατάσταση SE Installation



- GB Manual linking to alarm DE Manuelles Einlernen
- FR Liaison manuelle vers alarme NL Handmatig aan alarm koppelen
- FR Manuaalinen liittäminen OK Manuelt tilutning til alarm
- IT Collegamento manuale con allarme ES Enlazando manualmente a alarma
- PT Ligação manual ao alarme GR Χειροκίνητη σύνδεση σε σφύραξό
- SE Manuell länkning till larm



DE Installation **DE** Installation **FR** Installation
 NL Installatie **FR** Asennus **OK** Installation
 IT Installazione **ES** Instalación **PT** Instalação
GR Εγκατάσταση **SE** Installation



GR Exit alarm learn mode. Refer to online manual. **DE** Programmiermodus beenden.
 Siehe Handbuch. **FR** Quitter le mode apprentissage. Consulter le manuel en ligne.
NL Leermodus verlaten. Zie de online handleiding. **FI** Lopeta oppimistila.
 Katso käsikirja verkosta. **OK** Afslut programmeringsfunktion. Se den online vejledning.
IT Uscire dalla modalità di apprendimento. Fare riferimento al manuale online.
ES Salga del modo de aprendizaje. Consulte el manual en línea. **PT** Saia do modo
 de aprendizagem. Consulte o manual online. **GR** Έξοδος από τη λειτουργία μάθησης.
 Ανατρέξτε στο εγχειρίδιο στο διαδίκτυο. **SE** Avsluta läroläge. Se onlinehandbok.



GR Trouble shooting **DE** Fehlerbehebung **FR** Dépannage **NL** Probleemoplossing
FI Vianmääritys **OK** Problemlösning **IT** Risoluzione dei problemi **ES** Solución de
 problemas **PT** Resolução de problemas **GR** Αντιμετώπιση προβλημάτων **SE** Felsökning

livewell.honeywellhome.com



32305364-001 Rev.A