


05 Contents 05 Inhalt 05 Contenu 05 Inhoud 05 Sisältö
 06 Indhold 06 Contenido 06 Contento 06 Conteúdo
 06 Περιεχόμενα 06 Innehåll



x1



x1



x1



x1



x2



x2




x2





CR2032



x1




05 Getting started 05 Erste Schritte 05 Démarrage 05 Aan de slag 05 Aloitusopas 05 Kom i gang
 06 Operazioni preliminari 06 Para empezar 06 Para começãr 06 Πρώτα βήματα 06 Kom igång




x1





x1



4x AA/LR6




30mm






x1





x1



CR2032








15mm





0B Linking 0E Einleimen
 0F Programmation 0N Verknüpfung
 0I Linkittäminen 0X Forbände
 0T Collegamento 0S Enlace 0P Pro-
 gramação 0B Ουώδση 0E Länkning

0B Optional features 0E Optionale Funktionen 0F Options disponibles 0N Opções disponíveis
 0I Valinnaiset ominaisuudet 0X Valgtrite funktioner 0T Funzionalità opzionali 0S Opciones disponibles
 0P Funções opcionais 0B Προαιρετικές λειτουργίες 0E Möjliga funktioner



		3Hrs 			6Hrs
		9Hrs 			12Hrs



	Hello	Ding Dong	Westminster	Marimba	Piano	Bell	Telephone	Soft Alert
	•	•					•	•
	•	•	•				•	•
	•	•	•	•	•	•	•	•



0B Trouble shooting 0E Fehlerbehebung 0F Dépannage 0N Probleemplossing
 0I Vianmääritys 0X Problemløsning 0T Risoluzione dei problemi 0S Solución de
 problemas 0P Resolução de problemas 0B Αντιμετώπιση προβλημάτων 0E Felsöknig

livewell.honeywell.com



32310686-001 REVA