




DCR315XX

GB Contents DE Inhalt FR Contenu NL Inhoud FI Sisältö
 UK Inhold IT Contenuto ES Contenido PT Conteúdo
 CZ Obsah SE Innehåll HU Tartalom PL Zawartość
 HR Sadržaj RO Conținut SK Obsah




x1



x1



x1



x1



x2



x2




x2

















x1




CR2032




GB Getting started DE Erste Schritte FR Démarrage NL Aan de slag FI Aloitusohje
 UK Getting started IT Operazioni preliminari ES Para empezar PT Para começar
 CZ Krok za krokem SE Förberedelse HU Kezdő lépések PL Przygotowanie do użycia
 HR Početak rada RO Notiuni de baza SK Záči name



GB Optional features **DE** Optionale Funktionen **FR** Options disponibles **NL** Opties
FI Valinnaiset ominaisuudet **SK** Voliteľné funkcie **IT** Funzionalità opzionali
ES Opciones disponibles **PT** Funções opcionais **CZ** Volitelné funkce
SE Möjliga funktioner **HU** Opcionális funkciók **PL** Funkcje dodatkowe
HR Dodatne značajke **RU** Caracteristici optionale **SX** Voliteľné funkcie



	Hello	Ding dong	Westminster	Marrimba	Piano	Bell	Telephone	Soft alert	Glocken	Clock ding dong	Contemporary
	•	•					•	•			
	•	•	•				•	•			
	•	•	•	•	•		•	•	•		
	•	•	•	•			•	•	•	•	
	•	•	•	•			•	•	•	•	



	x2	3Hrs		x3	6Hrs
	x4	9Hrs		x5	12Hrs



GB Linking **DE** Verbinden **FR** Liaison
NL Koppelen **FI** Linkitys **SK** Tisúplňovanie
IT Collegamento **ES** Enlace **PT** Ligação
CZ Párovaní **SE** Länkning **HU** Összehangolás
PL Połączenie **HR** Povezivanje
RU Connectare **SX** Parovanie

GB Download full guide **DE** Vollständige Anleitung herunterladen
FR Télécharger le guide complet **NL** Volledige handleiding downloaden
FI Lataa koko opas **IT** Download den komplette vejledning
PT Descarregar a guia completa **CZ** Stáhnout podrobnou příručku
SE Ladda ned hela guiden **HU** Teljes útmutató letöltése
PL Pobierz pełny przewodnik **HR** Preuzmite cijeli vodič
RU Descărcăți ghidul complet **SX** Stiahnuť podrobnú príručku



GB Trouble shooting **DE** Fehlerbehebung **FR** Dépannage
NL Probleemoplossing **FI** Vianmääritys **SK** Problémotšňovanie
IT Risoluzione dei problemi **ES** Solución de problemas
PT Resolução de problemas **CZ** Odstranění poruch **SE** Felsökning
HU Hibakeresés **PL** Usuwanie usterek **HR** Rješavanje problema
RU Depanare **SX** Riešenie problémov

livewell.honeywellhome.com



32310686-001 Rev_B